

FELTEST manual Feltest Body Cooling equipment

How to use the Feltest Body Cooling vest?

To activate the vest, put it into water, drench it for 30 to 45 minutes and hang it to dry. When it's dry the vest is "Ready to Wear" and will produce comfortable cooling for a few days.



Please note:

The first time the vest is activated, it can happen that some of the pockets leak a surplus of the cooling gel. This is completely harmless and the excess gel can simply be washed away with water.



For **optimal cooling** effect, wear the vest tightly. You can [adjust the size](#) as shown in the picture to the right.

For **enhanced cooling** effect, put an activated vest additionally into a **fridge**. Directly from the refrigerator the vest produces intensive cold for approx. 10 minutes.

For **maximum cooling** effect, put an activated vest additionally into a **freezer**. The water will turn into ice and the vest produces extra intensive cold for several hours. Look out! It's necessary to wear an extra shirt underneath a frozen vest!

Cleaning

Put the vest into a washing machine on the "cold rinsing" program, **dry spinning it for a maximum of 1 minute**. If necessary, use a mild detergent.

Storage

When the vest will not be used for more than one...
... day, store it in a well-ventilated place
... week, let it dry a week in a well-ventilated place
before storing it



Front

Back

BODY COOLING by feltest.com

Specifications

- Cooling effect at Relative Humidity (RH): <70% RH: excellent; >80% RH: limited
- Activation time : 30- 45 minutes in cold water
- Operating time : 1 - 7 days, depending on use and conditions